NORGLASS LABORATORIES PTY LTD 1/59 Moxon Rd Punchbowl NSW 2196 Ph: 02 97082200 Fax: 02 97963069 Email: norglass@bigpond.net.au

Sep 2016

## **INFORMATION GUIDE**

## STAINING TIMBERS PRIOR TO CLEAR COATING

Where virgin timbers are presented for staining prior to coating, we recommend the following:

- 1. That the stain be of a solvent based product, so that the migration of the diluent is complete before coating. Where slow evaporating diluents are used (or water), some entrapment may occur, causing bubbles to appear.
- 2. During the application of the stainers, it will be necessary to go back over the applied area with solvent, to **re-distribute** the intensity of the stain, so that an even colour is achieved. Failure to do that will result in a blotchy unattractive finish.
- 3. It has to be stated, that the stains **must** be applied **directly** to the timber, **not after** the surface has been sealed or primed. The distribution of colour intensity can only be achieved whilst the surface is still absorbent.
- 4. Adequate drying times must elapse before applying Northane Clear, or any of our other clear finishes.

