

PRODUCT DATA SHEET

NORGLASS LABORATORIES PTY.LTD.

A.B.N. 92 001 807 245

P.O. Box 312, Neutral Bay. NSW 2089 Australia

59 Moxon Road, Punchbowl NSW

Ph: 61 2 9708 2200 Fax: 61 2 9796 3069

Email: norglass@bigpond.net.au

www.norglass.com.au



WEATHERFAST POLY CLEAR SATIN

DESCRIPTION: A one pack clear, low odour satin with excellent durability and abrasion resistance. (Read the information guide on “The Good Oil on Clear Coatings”.) Contains a high level of ultra violet screening agents making it suitable for exterior and interior use.

USES: Ideal for floors, furniture and all marine applications especially in heavy duty areas. Has very good water resistance, although not recommended for areas of constant immersion.

PROPERTIES (at 20°C)

COLOUR: Pale amber

TOXICITY: See precautions

FINISH: Satin

COVERAGE: Up to 12 sqm per litre

DRYING TIME: Touch dry 2-3 hours at 50% relative humidity

RECOATING: After 12 hours and 50% relative humidity

POT LIFE: N/A

MIXING RATIO: N/A

THINNING: Not recommended but up to 5% Weatherfast Brushing Thinner can be used in hot weather. If spraying use up to 20% Weatherfast Spraying Thinner.

WEIGHT/LITRE: 0.930kg

VOLUME SOLIDS:	43%
FLASH POINT:	32°C
CLEAN UP:	Weatherfast Brushing or Spraying Thinner
U.N. NUMBER:	1263
PREPARATION:	<p>Bare timber: Ensure the surface is clean, dry and well sanded. Remove all dust from the grain using a rag moistened in NORCLEAN-PLUS, NORGLASS EPOXY THINNER or ACETONE.</p> <p>Previously varnished timber: If the old coating is intact and in good condition, wash down with detergent and warm water and then wipe over with Norclean-Plus. Lightly sand to a dull finish. Cracked or peeling varnish must be removed back to clean timber otherwise a failure will result.</p>
APPLICATION:	<p>Varnishes or Clears should not normally be thinned for the first coat unless additional penetration is desired (on softwoods for example). Where thinning of the coating is carried out for this purpose, it is essential to extend the drying process for migration of the added solvents.</p> <p>The first 3-4 coats are best applied with a quality varnish brush allowing normal overnight drying and light sanding between coats.</p> <p>Subsequent coats can be applied by brush, roller or spray. The recommended roller is 4-5mm short nap mohair or microfibre.</p> <p>Where further coats are applied at intervals of not more than 4 weeks apart, sanding of the previous coat is not necessary.</p> <p>However, cleaning the surface of atmospheric and other contaminants with Norclean-Plus is essential. If spraying, up to 20% of NORGLASS WEATHERFAST SPRAYING THINNER can be added. Brushed coats should not be thinned but up to 5% of WEATHERFAST BRUSHING THINNER may be added in hot weather.</p>
TRANSPORTATION:	<p>DG Class 3 HAZCHEM 3Y P.G. III</p> <p>Sizes available: 4litre, 2litre, 1litre, 500ml and 250ml.</p>
PRECAUTIONS:	<p>Provide adequate ventilation during use.</p> <p>Do not smoke and keep away from naked flames.</p>
FIRST AID:	<p>If poisoning occurs call a doctor or Poisons Information Centre (Aust) on 13 11 26 or (NZ) 0800 764 766 and have label information ready.</p> <p>If swallowed DO NOT induce vomiting. Give large quantities of water or milk. In case of eye contact, flush immediately with plenty of water for at least 15 minutes and consult a doctor. Remove contact lenses if present and easy to do and continue rinsing. If skin contact causes irritation, remove contaminated clothing and wash skin thoroughly. If breathing difficulty arises remove to fresh air. Apply artificial respiration if not breathing.</p>

SPECIAL**INSTRUCTIONS:**

Do not use below 10°C as drying will be inhibited and moisture entrapment will likely impair the finish.

NOTE: Where an external satin finish is desired, a minimum of 3 - 4 coats of Weatherfast Poly Clear gloss must be applied **prior** to the final satin coat. This is to ensure that the surface absorption has been sealed in order to provide a uniform satin film.