

## PRODUCT DATA SHEET

**NORGLASS LABORATORIES PTY.LTD.**  
A.B.N. 92 001 807 245  
P.O. Box 312, Neutral Bay. NSW 2089 Australia  
59 Moxon Road, Punchbowl NSW  
Ph: 61 2 9708 2200 Fax: 61 2 9796 3069  
Email: [norglass@bigpond.net.au](mailto:norglass@bigpond.net.au)  
[www.norglass.com.au](http://www.norglass.com.au)



### MICROTALC

**DESCRIPTION:** A microfined white powder.

**USES:** As an extender with epoxy and polyester resins.

#### PROPERTIES (at 20°C)

**APPEARANCE:** White

**TOXICITY:** N/A

**FINISH:** Flat white

**COVERAGE:** Varies with resin consistency

**DRYING TIME:** N/A

**RECOATING:** Usually next day

**POTLIFE:** N/A

**MIXING RATIO:** Discretionary – usually 1:1 mixing ration by volume

**THINNING:** N/A

**WEIGHT/LITRE:** 450grams per litre

**VOLUME SOLIDS:** N/A

**FLASH POINT:** N/A

**CLEAN UP:** Norglass Epoxy Thinner

**UN NUMBER:** N/A

- PREPARATION:** Add MICROTALC to the base component and mix thoroughly before adding the hardener component. Spread the mix on a board or palette to reduce the thickness of the mix before applying to minimize heat development.
- APPLICATION:** Apply by trowel, squeegee or flat bladed knife.
- TRANSPORTATION:** No special arrangements required.
- PRECAUTIONS:** Wear gloves, goggles and mask when incorporating.
- FIRST AID:** If poisoning occurs call a doctor or Poisons Information Centre (Aust) on 1311 26 or (NZ) 0800 764 766 and have label information ready.  
If swallowed DO NOT induce vomiting. Should not cause harm if swallowed. In case of eye contact, flush immediately with plenty of water for at least 15 minutes and consult a doctor. Remove contact lenses if present and easy to do and continue rinsing. In case of skin contact, remove contaminated clothing and wash skin thoroughly. If breathing difficulty arises remove to fresh air. Apply artificial respiration if not breathing.
- SPECIAL INSTRUCTIONS:** N/A